



User manual

DELOCK[®]
we move the world

USB Bluetooth adapter EDR



Product-No: 61478

User manual No: 61478-a

www.delock.com



Description

The USB Bluetooth adapter enables a wireless communication or Data transfer e.g. between two PC's or a PC and a mobile phone.

Features

- Co-existent with 802.11 wireless carrier with no interference.
- Work as an audio Gateway (In/Out) on PC, with Bluetooth Headset to use MSN, Skype, Netmeeting and other internet messenger application.
- Allows user the ability to create a Bluetooth Personal Area Network with other compatible Bluetooth devices.

Specification

- USB 1.1 interface
- Bluetooth standard V2.0 EDR
- Class 2, operation range up to 80 meter
- Frequency range: 2.402-2.480 GHz 79 Channel FHSS
- Data transfer rate maximum 3 Mbps
- Plug & Play
- USB Bus power
- for Windows 98SE/ME/2000/XP

System requirements

- PC or Notebook with a USB Port
- Windows 98SE/ME/2000/XP

Package content

- USB Bluetooth adapter
- Driver CD
- User manual

*Make sure that product package contains all items before operation. If any item is missing or damaged, then please contact your dealer immediately.

Note:

Follow the general instructions for installation of the adapter. If necessary, read the manual of your computer, or ask a specialist for help.



Driver Installation

Windows 2000/XP Service pack 1 and 2

1. Switch on your computer.
2. Insert the driver CD in the CD ROM drive.
3. Setup Program will open automatically.
4. Choose "Install" and click on "next".
5. Read the license agreement and confirm it by "I accept the terms in the license agreement" and click on "next".
6. Click "Install" and click on "Yes".
7. As soon as the message appears "connect the Bluetooth adapter", plug the USB Bluetooth adapter to a free USB Port. After that click on "ok".
8. Click on "Finish", after that on "Yes", to restart the computer.
9. After rebooting the device is ready for use.

Start a Bluetooth connection:

1. Click on the Bluetooth Logo in your taskbar.
2. The assistant for a new connection appears.
3. Choose "Express Modus" and click "next".
4. There will be different Bluetooth devices found, choose the one which you will connect with your computer.
5. Possibly you have to enter a key for this devices.
6. Choose a name and click "next", after that on "Finish".
7. You can see the device in your Bluetooth program. In order to connect your device please "Double click" on the icon.

Windows 98/98SE/ME

1. Switch on your computer.
2. Insert the driver CD in the CD ROM drive.
3. Setup Program will open automatically.
4. Choose "Install" and click on "next".
5. Read the license agreement and confirm it by "I accept the terms in the license agreement" and click on "next".
6. Click "Install" and click on "Yes", "Finish".
7. Click "Yes" to restart your PC.
8. After rebooting connect the USB Bluetooth adapter to a free USB Port.
9. The new Hardware will be recognized and you can start using the device immediately.



Start a Bluetooth connection:

1. Go to "Start", "program", "Bluetooth", "Bluetooth Service Manager".
2. All other Bluetooth devices will be searched automatically and connected.

Support Delock

If you have further questions, please contact our customer support
support@delock.de / www.delock.de or phone
0700 - DELOCKGE (0700 - 335 625 43).

You can contact our service hotline during the following times:

Mon – Fri: 9:00 – 17:30 pm charge 0,12 € / min*

* A connection fee applies according to fee schedule of Deutsche Telekom AG or your local telephone provider.

All callers outside of Germany dial please 00493081789324

You can find current product information on our homepage: www.delock.de

Final clause

Information and data contained in this manual are subject to change without notice in advance. Errors and misprints excepted.

Copyright

No part of this user's manual may be reproduced, or transmitted for any purpose, regardless in which way or by which means, electronically or mechanically, without explicit written approval of Delock.