



User manual

**DELOCK**<sup>®</sup>  
we move the world

## PCMCIA PC-Card CardReader 20 in 1



Product-No: 91403  
User manual No: 91403-a  
[www.delock.com](http://www.delock.com)



---

## Description

The DeLock CardReader enables you to read these different memory cards via the PCMCIA drive of your notebook. You can read and write 20 different memory card.

## Specification

- 16-Bit PC-Card
- Supports following memory cards:  
Memory Stick, Memory Stick Select, Memory Stick Duo (with MS Duo adapter), Memory Stick Pro, Memory Stick Duo MagicGate (with MS Duo adapter), Memory Stick Duo Pro (with MS Duo adapter), Memory Stick Pro MagicGate, Memory Stick MagicGate, Memory Stick Duo MagicGate (with MS Duo adapter), SD, mini SD (with SD adapter), Micro SD - T-flash (with SD adapter), SD High Capacity (SDHC), MMC, RS-MMC (with MMC adapter), MMC Dual Voltage, RS-MMC Dual Voltage (with MMC adapter), xD, xD type M, xD type H
- Supports memory:
  - with SD up to 1GB, SD 1.0, 1.1, 2.0 up to 32GB
  - with MMC up to 1GB
  - with xD up to 2 GB
  - with MS Types up to 256 MB
  - with MS Pro Types up to 4 GB
- Hot Swap, Plug & Play
- For Windows 98/98SE/ME/2000/XP, Mac 8.6 and higher

## System requirements

- PC or Notebook with a PCMCIA Slot
- Windows 98/98SE/ME/2000/XP, Mac OS 10.2.8 and higher

## Package content\*

- PC-Card CardReader 20 in 1
- User manual

\*Make sure that the product package contains all items before operation. If any item is missing or damaged, then please contact your dealer immediately.

## Note:

Follow the general instructions for installation of the CardReader. If necessary, read the manual of your computer, or ask a specialist for help.



---

## **Driver Installation**

1. Switch on your computer.
2. Insert the CardReader into your PCMCIA Slot.
3. The driver will be found automatically and installed.
4. You can now start to use the device.

## **Support Delock**

If you have further questions, please contact our customer support  
support@delock.de / www.delock.com or phone  
0700 - DELOCKGE (0700 - 335 625 43).

You can contact our service hotline during the following times:

Mon – Fri: 9:00 – 17:30 pm charge 0,12 € / min\*

\* A connection fee applies according to fee schedule of Deutsche Telekom AG  
or your local telephone provider.

All callers outside of Germany dial please 00493081789324

You can find current product information on our homepage:  
www.delock.com

## **Final clause**

Information and data contained in this manual are subject to change without  
notice in advance. Errors and misprints excepted.

## **Copyright**

No part of this user manual may be reproduced, or transmitted for any purpose,  
regardless in which way or by which means, electronically or mechanically,  
without explicit written approval of Delock.